




LIQUID COMBUSTION TECHNOLOGY
GEN I 291CC MANUAL START
SUMMER RESIDENTIAL ENGINE
SERVICE PARTS FOR MODEL NUMBER
PLMHK03850124BPSTUVE2M
PLMHK03850124BPSE2

CPC
Part No.

LCT
Ref No.



1	Cylinder Head Assembly	29110001	SK2911000.1
2	Push Rod Tappet Kit	29110011	SK2911001.1
3	Valve Cover Assembly	41445001	SK4144500.1
4	Choke Lever, Carburetor	41421201	SK4142120.1
5	Piston Assembly	29114001	SK2911400.1
6	Connecting Rod Assembly	29115001	SK2911500.1
8	Flywheel Assembly, Manual Start	29117001	SK2911700.1
9	Flywheel Fan	29140001	SK2914000.1
10	Crankshaft	29118001	SK2911800.1
11	Air Filter Assembly of Paper	41420021	SK4142002.1
12	Filter Element, Panel Paper	41420121	SK4142012.1
13A	Muffler Assembly	29121001	SK2912100.1
14A	Fuel Tank Assembly	41422041	SK4142204.1
15	Fuel Petcock	41422201	SK4142220.1
16A	Plastic Fuel Cap (Click Style)	41483001	SK4148300.1
17	Carburetor Assembly	29124001	SK2912400.1
18	Ignition Coil Assembly	29125001	SK2912500.1
19	CDI Box Assembly	29127501	SK2912750.1
20	On/Off Switch	20826001	SK2082600.1
21	Non-Removable Oil Plug	41437151	SK4143715.1
22	Black Oil Dipstick	41437111	SK4143711.1
23	Fuel Hose Kit	41460001	SK4146000.1
24	Throttle Control Assembly	29128001	SK2912800.1
25	Governor Gear Assembly	29129001	SK2912900.1
26	Governor Link Assembly	29130001	SK2913000.1
27	Governor Arm Shaft Assembly	29131001	SK2913100.1
28	Recoil Starter Assembly	29132001	SK2913200.1
29	Starter Cup	29133001	SK2913300.1
30	Blower Housing Assembly	29134001	SK2913400.1
31	Crankcase Cover Assembly	29136001	SK2913600.1
32	Seal Kit	29139001	SK2913900.1
34	Spark Plug Boot	29138001	SK2913800.1
36	Engine Gasket Kit	29143001	SK2914300.1
37	Low Oil Sensor	29127001	SK2912700.1
39	Camshaft	29116001	SK2911600.1
41	Spark Plug	29115501	SK2911550.1
43	Rocker Arm Kit	41411001	SK4141100.1
44	Cylinder Assembly	29113001	SK2911300.1
47	Foam Pre-Filter	41490011	SK4149001.1
49	Oil Drain Plug Assy	41499111	SK4149911.1